



177 DIXON RD.  
LEBANON, ME. 04027  
TEL: 207-658-7758 FAX: 207-658-4337  
www.directivesystems.com

## 2401 MHz Loop Yagi Model 1252LY

### SPECIFICATIONS

Frequency range:	2.3 to 2.45 GHz
Number of elements:	52
Boom length:	96 inches
Boom diameter:	0.5 inch
Mast diameter:	1 inch
Weight:	3 pounds
Connector:	Type-N female
Gain:	$\cong$ 21 dBi
3 dB Beamwidth (E plane):	$\cong$ 14 degrees
F/B ratio:	$\geq$ 20 dB
Maximum Power:	400 watts average
Stacking distance:	13 inches vertical 15 inches horizontal

### ASSEMBLY INSTRUCTIONS

- 1) Unpack the antenna and locate the hardware package. Some antennas are shipped in two sections, in which case the boom is broken between directors 25 & 26. Remove D24 and D25 from the rear boom section and slide the two boom pieces together. Align the elements. Replace D24 & D25 and retighten.
- 2) Attach the boom to Mast angle bracket to the boom with the hardware provided. Install the U-Bolt. The antenna will be horizontally polarized when installed on a horizontal cross boom ( For OSCAR use) or vertically polarized when installed on a vertical support mast
- 3) Attach the feedline and tape it to the bottom of the boom. The connector should be sealed with silicone RTV or equivalent.
- 4) Straighten any mis aligned elements and re-tighten if necessary.
- 5) The antenna SWR has been adjusted at the factory for less than 1.2:1 mismatch. Additional tweaking can be accomplished by changing the shape of the driven element slightly and by adjusting the distance between the driven element and R1 and D1. R1 is the reflector closest to the driven element.
- 6) If antennas are to be stacked, see " Instructions for Stacking Loop Yagis."