



DIRECTIVE SYSTEMS

177 DIXON RD.
LEBANON, ME. 04027
TEL: 207-658-7758 FAX: 207-658-4337
www.directivesystems.com

1296 MHz Loop Yagi, Model 2355LY

SPECIFICATIONS

Frequency Range:	1.25-1.30 GHz
Number of elements:	55
Boom Length:	180 inches
Boom diameter:	1 inch
Mast diameter:	1 1/2 inch max.
Weight:	7 pounds
Connector:	Type N female
Gain:	21 dBi
3 dB Beamwidth (E Plane) :	=14°
F/B ratio:	≥20 dB
Maximum Power:	550 W. average
Stacking distance:	27 inches vertical 30 inches horizontal

ASSEMBLY INSTRUCTIONS

- 1) Unpack antenna and locate the three preassembled antenna sections and the hardware package. The boom is broken between elements D21 and D22 & D42 and D43. Remove D22 & D43 from the boom pieces and slide boom pieces together to alignment marks. Replace D22 & D43 and retighten. (D22 is the element approximately 0.5 inch from the end of the boom section; it will only fit together one way.) The booms are marked for your assembly.
- 2) Attach the boom to mast plate to the boom with the hardware provided. Install the U-bolts so that the mast comes up directly under the boom.
- 3) Attach the feed line, and tape it to the bottom of the boom. The connector should be sealed with electronic grade RTV or equivalent. Don't forget to seal the area where the .141" semi rigid coaxial cable extends into the rear of the antenna connector.
- 4) Straighten any mis aligned elements and tighten hardware if necessary.
- 5) The antenna SWR has been adjusted at the factory for less than 1.3:1. Additional tweaking can be accomplished by adjusting the distance between the driven element and R1 and D1, or by adjusting the shape of the driven element. If you do not have good VSWR measuring equipment, you could degrade performance!
- 6) If antennas are to be stacked, see "Instructions For Stacking Loop Yagis"
- 7) Enjoy your new antenna, good DX.